使用说明 Instruction

1.确认鼠标底部开关已拨至"OFF"状态; 开盖轻按上盖并下拉即可(因磁铁吸附功能, 直接下拉, 则无法打开)

2.装入一节A A碱性电池, 取出USB接收器并扣上电池上盖, 将电源开关拨至"ON"位置; 将USB接收器插入电脑USB端口。

3.(1)短按对码键(小于3秒): 切换鼠标连接模式(绿灯为2.4G模式,蓝灯为蓝牙模式)

(2)长按对码键(超过3秒): 强制进入蓝牙对码模式(蓝灯快闪)

(3)长按组合键(左键+右键+中键):强制进入2.4GHz对码模式(绿灯快闪)

(4) 蓝牙有效配对时间: 3分钟 (5) 2.4GHz有效配对时间: 20秒

(6)断开重连时间:5秒

4.蓝牙配对: (1)长按对码键,蓝灯快闪 (2)电脑打开蓝牙,添加蓝牙设备 (3)找到蓝牙名【BT 4.0+2.4G MOUSE】点击链接 (4)蓝灯停止快闪变成慢闪,连接成功

5.2.4GHz配对: (1) 电脑插好接收器 (2)长按组合键(左键+右键+中键), 直到绿灯快闪 (3)鼠标靠近接收器 (4)绿灯停止快闪变成慢闪,连接成功

6.光提示: (1) 绿灯快闪: 2.4GHz对码模式 (2) 绿色慢闪: 2.4GHz工作模式 (3)蓝色快闪: 蓝牙对码模式 (4)蓝色慢闪: 蓝牙工作模式

7.鼠标出厂默认DPI为1000, 设1000、1600、2400三挡, 您可通过组合键(中键+右键) 三秒进行切换。

1.Make sure the power button at the bottom has been turned to "OFF", then open the battety; Press the cover and pull down to open(pull down directly can not open due to magnetic attached)

2.Put a AA battery in and take out the USB receiver, attach the cover and switch on the mouse; Plug the micro receiver into the USB port of your computer

3.(1) Short press the code key(less than 3 seconds): Switch mouse connection mode(green light is 2.4Gmode, blue light is Bluetooth mode) (2) Press and hold the code key(more than 3 seconds): Forced entry into Bluetooth code matching mode(blue light flashing) (3) Long press left&right&middle key: Forced entry into 2.4GHz code matching mode(green light flashing) (4) Bluetooth effective pairing time: 3 minutes (5) 2.4GHz effective pairing time: 20 seconds (6) Disconnection and reconnection time: 5 seconds.

4.Bluetooth pairing: (1)Long press the code key and the blue light will flash (2)Turn on Bluetooth and add Bluetooth devices on the computer (3)Find the Bluetooth name[bt 4.0+2.4g mouse] and click the link (4)The blue light stops flashing fast and turns to slow flashing, and the connection is successful

5.2.4GHz pairing: (1) Plug in the receiver in the computer (2) Long press the left&right&middle key, Until the green light flashes (3) Put themouse close to the receiver (4) The green light stops flashing fast and turns to slow flashing, and the connection is successful

6.Lighting: (1) Green light flashing fast: 2.4GHz code matching mode (2) Green light blinking slowly: 2.4GHz working mode (3) Blue light flashing fast: Bluetooth code matching mode (4) Blue light blinking slowly: Bluetooth working mode

7.The default DPI of the mouse is 1000, which can be adjusted in 1000, 1600 and 2400. You can switch through the combination of keys (middle+right) 3 seconds







